



MEASURING WHAT'S NEXT™

---

## VERA CALIBRATION INSTRUCTIONS

1. While the scale is off, press and hold the **POWER/TARE** and **UNIT** buttons down simultaneously until a digital range of (-4000-8000) appears on display.
2. Press the **UNIT** button; "0.0g" will briefly appear and the required weight for calibration will be displayed: 2000g (2 kg)
3. Gently place the required weight onto the center of the scale platform. Once the required weight is placed onto the platform, calibration will automatically begin.
4. If "PASS" is displayed, this indicates successful calibration. ("EEEE" if calibration failed.)
5. Calibration is now completed; power the scale off and restart.